

R 332 Z

Tractor with ballast weight



R 332 Z

The tractor R 332 Z is used for the transportation of bulky, heavy loads on drawbar trailers mostly operated in heavy industry for coils and steel slabs.

A ballast weight dimensioned according to the payload is mounted on the rear axle of the vehicle and transfers the necessary traction of the rear wheels to the ground. For easy handling brake hoses and electrical connection hoses are placed next to the trailer coupling.

There is a choice of trailer couplings suited for different payloads. Optionally the tractor will be equipped with fixed or detachable ballast weight and with or without hydraulically elevating 5th wheel. The detachable ballast weight can be parked in a separate frame stand while the tractor with 5th wheel will be used for shunting semi-trailers. Rubber and steel mudguards are also available for splash and accident protection. Please refer to the Technical Data sheet R 332/ R 336 for further technical details and options.



With fixed ballast weight



With trailer coupling at front



With detachable ballast weight on 5th wheel



With coupled heavy-duty trailer

